

Piese schimb si consumabile

Nr. crt.	Articol
1	AF Platenclene 100 ml pump can (10388)/10388
2	Cablu alimentare 1.8 m/Depozit
3	Cartus toner compatibil HP Q2612A LJ1010 CRG 703
4	Charge corona unit pentru BH C220/280/360/7053
5	Charge corona unit pentru BH C224/284/364/224e/284e/364e/7054
6	Chip IU Black 220V pentru IU 610K BH C451/550/650/8708
7	Chip IU Black pentru BH C250/252 IU-210K/5694
8	Chip IU Black pentru BH C452/552/652/8262
9	Chip IU Cyan pentru BH C200/203/353 IU-212C/8701
10	Chip IU Cyan pentru BH C250/252 IU-210C/5697
11	Chip IU Cyan pentru BH C452/552/652/8263
12	Chip IU Magenta 220V pentru IU 610M BH C451/550/650/8711
13	Chip IU Magenta pentru BH C250/252 IU-210M/5708
14	Chip IU Magenta pentru BH C452/552/652/8264
15	Chip IU Y/M/C pentru BH C220/280/360/8314
16	Chip IU Y/M/C pentru BH C224/284/364/8207
17	Chip IU Yellow 220V pentru IU 610Y BH C451/550/650/8710
18	Chip IU Yellow pentru BH C200/203/353 IU-212Y/8702
19	Chip IU black pentru BH C224/284/364/8200
20	Chip Minolta BH 40P 19K
21	Chip Minolta BH C250 yellow 12K
22	Chip toner PAGEPRO 5650 18K
23	Chip toner black pentru BH C20 8K

Nr. crt.	Articol
24	Chip toner black pentru BH C200/203/253/353/5964
25	Chip toner black pentru BH C250/252/5691
26	Chip toner black pentru BH C451/550/650 TN 411K/8712
27	Chip toner cyan pentru BH C200/203/253/353/5965
28	Chip toner cyan pentru BH C250/252/5707
29	Chip toner cyan pentru BH C451/550/650 TN 411C/8713
30	Chip toner magenta pentru BH C200/203/253/353/5967
31	Chip toner magenta pentru BH C250/252/5693
32	Chip toner yellow pentru BH C200/203/253/353/5966
33	Chip toner yellow pentru BH C250/252/5692
34	Chip toner yellow pentru BH C451/550/650 TN 411Y/8714
35	Cilindru + lamela Canon IR 1600 2016/2018/2022
36	Cilindru Minolta PAGEPRO 1300 PP1100 PP1350 PP1400 EPSON EPL 6200
37	Cilindru PP5650
38	Cleaning Web Assembly pentru BH 601/30175
39	Cleaning web assembly HP LJ 9055 (23610)/23610
40	Corona wire spool/11002
41	Cyanolube adhesive/12499
42	DV 311 Black Developer pentru BH C220/280/360 210g/8436
43	DV 512C pentru BH C224/284/364/454/554/8126
44	DV 512K pentru BH C224/284/364/454/554/8125
45	DV 512M pentru BH C224/284/364/454/554/8127
46	DV 512Y pentru BH C224/284/364/454/554/8128
47	Developer C pentru BH C250/C252 210g/6904

Nr. crt.	Articol
48	Developer M pentru BH C203/C253/C353 250g/6826
49	Developer M pentru BH C250/C252 210g/6906
50	Developer Y pentru BH C250/C252 210g/6905
51	Developer chip pentru BH C220/280/360/284/224e/284e/364e..../8230
52	Developer gear kit pentru Di152/1611/7333
53	Developer pentru BH C451/550/650 IU-610M/6948
54	Display Minolta BH C250
55	Drum Cleaning Blade pentru Bizhub 162/210/4662
56	Drum Cleaning Blade pentru Di 750/Konica -7075/4639
57	Drum cl. blade pentru DR311 BH C220/280/360/3724
58	Drum cleaning blade assembly pentru BH420/500/3509
59	Drum cleaning blade color pentru BH C451/550/650/9017
60	Drum cleaning blade color pentru BH C452/552/652/7030
61	Drum cleaning blade pentru BH C224/284/364/224e/284e/364e/7016
62	Drum cleaning blade pentru EP Di152/21876
63	Drum unit rebuild kit Cyan pentru Bizhub C250/252/3767
64	Drum unit rebuild kit Magenta pentru Bizhub C250/252/3768
65	Drum unit rebuild kit Yellow pentru Bizhub C250/252/3769
66	Drum unit rebuild kit cyan pentru BH C452/552/652/7046
67	Drum unit rebuild kit pentru BH 223/363/39437
68	Drum unit rebuild kit pt BH C203/253/353 IU-211M, IU-313M/6484
69	Drum unit rebuild kit pt BH C203/253/353 IU-211Y, IU-313Y/6483
70	Drum unit rebuild kit pt Minolta Bh 250/350/351/2510/5390
71	Fuser belt pentru BH C203/253/353/7013

Nr. crt.	Articol
72	Fuser belt pentru BH C220/280/360/224/284/364/454/224e/284e/364e/7014
73	Fuser cleaning roller pentru BH C452/552/652/7031
74	Fuser cleaning web Minolta pentru Di750/850/B920/950/4039
75	Fuser cleaning web pentru BH PRO 1051/1200/1200P/7065
76	Lower Sleeved Roller BH 420/500/3582
77	Lower Sleeved Roller BH164/184/7718/6520
78	Lower Sleeved Roller Di250/Di350/03249
79	Lower pressure roller pentru Bh 250/282/25296
80	Lower sleeved roller W/ bearing pentru BH Pro 1051/1200/7078
81	Lower sleeved roller W/bearing pentru BH Pro 920/950/7093
82	Lower sleeved roller pentru BH C250/252/3541
83	Lower sleeved roller pentru BH C454/454e/7060
84	Lower sleeved roller pt. BH 223/283/363/423/7076
85	Siguranta pentru resetare (10515)/10515
86	Transfer belt pentru BH C220/280/360/7120
87	Ultraclens (23888)/23888
88	Upper Fuser Roller pentru Minolta Bizhub C350/351/450/3573
89	Upper fuser roller pentru BH 162/210/3022
90	Upper fuser roller pt. BH 164/184/7718/6519
91	Upper sleeved roller pentru BH C250/252/3540
92	Vinyl/plastic tape 1700/707205